DRAWINGS: TRADITIONAL DETAILS

Al	TYPICAL FLANGE STYLE WINDOW PENETRATION	H5	BOTTOM OF WALL AT TOP OF ROOF
A2-3	TYPICAL FLANGE STYLE WINDOW PENETRATION	Н6	TRADITIONAL ROOF/WALL INTERSECTION KICKOUT FLASHING
A4-5	TYPICAL FLANGE STYLE WINDOW PENETRATION	Н7	TERMINATION AT DECK
A6	TYPICAL FLANGE STYLE WINDOW PENETRATION	Н8	VINYL DECK DETAIL
Al0-11	PREPARATION FOR WINDOW PENETRATION ARCHED TOP FLANGE STYLE WINDOWS	Н9	DRIP THROUGH DECK DETAIL CROSS SECTION
A12-13	PREPARATION FOR WINDOW PENETRATION ARCHED TOP FLANGE STYLE WINDOW	Pl	DRYER VENT PENETRATION
A14	PREPARATION FOR WINDOW PENETRATION ARCHED	P2	HOSE RIB PENETRATION
Alt	TOP FLANGE STYLE WINDOWS	SI	SOFFIT DETAIL WITH VENT
A16	TYPICAL FLANGE STYLE ROUND WINDOW PENETRATION	S2	SOFFIT DETAIL (SLOPING)
Cl	HORIZONTAL CONTROL JOINT THROUGH WALL FLASHING	Tl-12	STUCCO DIRECT TO CONCRET MASONRY UNIT STUCCO TO C.M.U. WITH LATH
C2	HORIZONTAL CONTROL JOINT THROUGH 'W' FLASHING		STOCCO TO C.M.O. WITH LATH
D1-2	WEEP SCREEN AT CONCRETE CASING BEAD AT CONCRETE	T3-T4	STUCCO DIRECT TO CONCRETE STUCCO TO CONCRETE WITH LATH
D3-4	CASING BEAD FLASHING AT CONCRETE WOOD TRIM AT CONCRETE	T5	FINISH COAT DIRECT TO CONCRETE
E1	INTERIOR CORNER	T6	PREPARATION FOR SADDLE FLASHING
E2	INTERIOR CORNER	T6a	PREPARATION FOR SADDLE FLASHING
	CORNER LATH ALTERNATE	T6b	PREPARATION FOR SADDLE FLASHING
E3	INTERIOR CORNER CONTROL JOINT ALTERNATE	T6c	PREPARATIO FOR SADDLE FLASHING
F1	VERTICAL CONTROL JOINT	T7	SADDLE FLASHING DETAIL
F2	VERTICAL JOINT STUCCO TO OTHER CLADDING	-,	
F3	VERTICAL JOINT C.M.U. (FLUSH)		
F4	VERTICAL JOINT C.M.U.		
G1	STUCCO 1 OTHER CLADDING HORIZONTAL JOINT		
HI	TERMINATION AT PARAPET		

GENERIC DETAIL ONLY


Use of this design subject to approval for specific project




H2


TERMINATION AT ROOF

H3-4 RAILING AT CAPPED WALL RAILING MOUNTING





LAP SILL FLASHING PAPER INTO ROUGH OPENING.SLIT BOTH ENDS MIN. 10". FOLD UP RIGHT AND LEFT ROUGH JAMB AND ALONG FACE.



STEP 2

LAP JAMB FLASHING PAPER INTO ROUGH OPENING. SLIT BOTTOM END MIN. 10", FOLD ONTO SILL FLASHING AND ALONG FACE.

GENERIC DETAIL ONLY

Use of this design subject to approval for specific project

TITLE

PREPARATION FOR WINDOW PENETRATION ARCHED TOP FLANGE STYLE WINDOW


EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO


A10 - 11

JUNE 2016



STEP 3a

INSTALL TOP FLASHING PAPER ON TOP EGE OF ROUGH OPENING. **ENSURE (FULL 4" MIN. OVERLAP) OF EACH SIDE FLASHING.**



STEP 3b - Alternate

INSTALL SELF HEALING MEMBRANE TO SILL AND JAMB FLASHING PAPERS **ENSURING ALL GAPS AND HOLES ARE SEALED. DO NOT APPLY SELF HEALING MEMBRANE ONTO SHEATHING.**

GENERIC DETAIL ONLY

Use of this design subject to approval for specific project


PREPARATION FOR WINDOW **PENETRATION** ARCHED TOP FLANGE STYLE WINDOW

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886




DWG NO

A12 - 13



STEP 5a

INSTALL GALVANIZED METAL HEAD FLASHING OVER TOP OF WINDOW FLANGE. USE FLASHING FORMED TO SUIT WINDOW PROFILE. FLASHING TO HAVE HORIZONTAL SECTION WITH END DAMS.



TEP 5b (Alternate)

APPLY SELF HEALING MEMBRANE TO EACH WINDOW SIDE PRIOR TO METAL HEAD FLASHING. AFTER INSTALLING HEAD FLASHING, APPLY ONE STRIP OF SELF HEALING MEMBRANE **OVER GALVANIZED METAL HEAD FLASHING EXTENDING UP ONTO BARE WOOD.**

GENERIC DETAIL ONLY

Use of this design subject to approval for specific project


PREPARATION FOR WINDOW **PENETRATION** ARCHED TOP FLANGE STYLE WINDOW

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO

A14



Use of this design subject to approval for specific project


TYPICAL FLANGE STYLE ROUND WINDOW PEETRATION

EZWALL Coatings, Inc. **1001 Forest Avenue** Dallas, Texas 75215 214-428-1886




DWG NO

A16



LAP SILL FLASHING PAPER INTO **ROUGH OPENING. SLIT BOTH ENDS** MIN. 10", FOLD UP RIGHT AND LEFT ROUGH JAMB AND ALONG FACE.



STEP 2

LAP JAMB FLASHING PAPER INTO ROUGH OPENING. SLIT BOTTOM END MIN. 10", FOLD ONTO SILL FLASHING AND ALONG FACE.

GENERIC DETAIL ONLY

Use of this design subject to approval for specific project


TYPICAL FLANGE STYLE WINDOW PENETRATION

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886




DWG NO

A2-A3




STEP 3a

INSTALL TOP FLASHING PAPER ON TOP EDGE OF ROUGH OPENING. **ENSURE FULL OVERLAP OF EACH** SIDE FLASHING.



STEP 3b-(Alternate)

INSTALL SELF HEALING MEMBRANE TO SILL AND JAMB FLASHING PAPERS **ENSURE ALL GAPS AND HOLES ARE SEALED. DO NOT APPLY SELF ADHERING MEMBRANE ONTO SHEATHING.**



STEP 4

INSTALL WINDOW ON PROPERLY FLASHED OPENING.

NOTE:

PROVIDE CAULKING AS PER NBC 9.27.4

GENERIC DETAIL ONLY


Use of this design subject to approval for specific project

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886

ezwall DATE JUNE 2016


DWG NO

A4-A5



STEP 5a

INSTALL GALVANIZED METAL HEAD FLASHING OVER TOP OF WINDOW FLANGE, ENSURE FLASHING EXTENDS PAST EACH SIDE OF WINDOW FRAME 1".



STEP 5b-(Alternate)

APPLY SELF HEALING MEMBRANE TO EACH OF WINDOW SIDES PRIOR TO METAL HEAD FLASHING. AFTER INSTALLING HEAD FLASHING, APPLY ONE STRIP OF SELF HEALING MEMBRANE OVER GALVANIZED METAL HEAD FLASHING EXTENDING UP ONTO BARE WOOD.

GENERIC DETAIL ONLY

Use of this design subject to approval for specific project


TYPICAL FLANGE STYLE WINDOW PENETRATION


EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO


A6





NOTES:

- 1. ONLY BE USED WHERE WOOD SHRINKAGE WILL BE MINIMUM THIS JOINT WILL NOT ACCOMMODATE SHRINKAGE BEYOND 1/4" TO 3/8".
- 2. JOINTS TO BE PROPERLY SEALED
- 3. ENSURE 'W FLASHING IS FILLED WITH BASECOAT TO FULL THICKNESS. FINISH COAT TO FULLY COVER THE FLASHING.
- 4. UNEVEN FRAMING TO BE INSPECTED



HORIZONTAL CONTROL JOINT 'W' FLASHING


EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886


ezwall June 2016

DWG NO

GENERIC DETAIL ONLY

Use of this design subject to approval for specific project





Use of this design subject to approval for specific project

WEEP SCREEN AT CONCRETE 1 CASING BEAD AT CONCRETE


TITLE


EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO D1-D2

DATE June 2016





Use of this design subject to approval for specific project


CASING BEAD FLASHING AT CONCRETE WOOD TRIM AT CONCRETE


EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO

D3-D4







Use of this design subject to approval for specific project

INTERIOR CORNER

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886 ezwall

DWG NO






Use of this design subject to approval for specific project


INTERIOR CORNER CORNER LATH ALTERNATE

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO





Use of this design subject to approval for specific project


INTERIOR CORNER CONTROL JOINT ALTERNATE

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO

DATE NOV. 2016




Use of this design subject to approval for specific project

VERTICAL CONTROL JOINT

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO



Use of this design subject to approval for specific project

TITLE

VERTICAL JOINT STUCCO TO OTHER CLADDING


EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO

F2

DATEBCJ "'&\$%




NOTE: PRAMING DETAIL OF STUD WALL TO MANSONRY WALL BY OTHERS.

GENERIC DETAIL ONLY

Use of this design subject to approval for specific project

DWG NO

ezwali DATE NOV. 2016




MOTE: FRAMING DETAIL OF STUD WALL TO MANSONRY WALL BY OTHERS.

GENERIC DETAIL ONLY

Use of this design subject to approval for specific project

DWG NO


ezwali DATE NOV. 2016



Use of this design subject to approval for specific project

DWG NO


ezwall DATE NOV. 2016



Use of this design subject to approval for specific project

ezwall DWG NO H1
DATE NOV. 2016

DWG NO




Use of this design subject to approval for specific project


TERMINATION AT ROOF

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO





Use of this design subject to approval for specific project

RAILING AT CAPPED WALL RAILING MOUNTING

TITLE


EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO

H3-H4


DATE Jan. 2017




Use of this design subject to approval for specific project


DWG NO

ezwall H5
DATE Jan. 2017





Use of this design subject to approval for specific project




Use of this design subject to approval for specific project

DWG NO

ezwall H8

DATE Jan. 2017




Use of this design subject to approval for specific project

DRIP THROUGH DECK DETAIL CROSS SECTION

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO



DRYER VENT PENETRATION


EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886

ezwall

DWG NO


P1


DATE Feb. 2017



EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886 ezwall

DATE Feb. 2017





NOTE: SOFFIT SHOULD SLOPE MIN 1/8" PER FOOT HORIZONTAL AWAY FROM BUILDING.

GENERIC DETAIL ONLY

Use of this design subject to approval for specific project

DWG NO


S2


SZ

SOFFIT DETAIL (SLOPING)

TITLE

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886







STUCCO TO CONCRETE MASONRY UNITS WITH LATH - STUCCO DIRECT TO CONCRETE MASONRY UNITS

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886 DWG NO

T1-T2

PATE March 2017






Use of this design subject to approval for specific project

DWG NO

T3-T4

ezwali March 2017



NOTE: SUBSTRATE MUST BE CLEAN AND FREE OF DELETERIOUS MATERIALS.

GENERIC DETAIL ONLY


Use of this design subject to approval for specific project


TITLE

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886

ezwalli March 2017

DWG NO





STEP 2

GENERIC DETAIL ONLY

Use of this design subject to approval for specific project

TITLE


PREPARATION FOR SADDLE **FLASHING**


EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO

T-6





GENERIC DETAIL ONLY

Use of this design subject to approval for specific project

PREPARATION FOR SADDLE FLASHING


EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886




DWG NO

T-6a

March 2017






GENERIC DETAIL ONLY

Use of this design subject to approval for specific project

DWG NO

T-6b

ezwall



(a) INSTALL BUILDING PAPER ABOVE PARAPET SHINGLING ON TOP OF PREVIOUS MEMBRANES.

(b) INSTALL STUCCO STOPS AROUND TERMINATION.

GENERIC DETAIL ONLY

Use of this design subject to approval for specific project


PREPARATION FOR SADDLE **FLASHING**

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886

ezwall

DWG NO

T-6c



Use of this design subject to approval for specific project

SADDLE FLASHING DETAIL

EZWALL Coatings, Inc. 1001 Forest Avenue Dallas, Texas 75215 214-428-1886



DWG NO

T-7